

Schatten Hammered Dulcimer Pickup System Model HD2

Thank you for purchasing one of our hammered dulcimer pickup systems. Each pickup is carefully hand built and tested to ensure that it meets our high standards for quality and durability.

Installation Instructions:

- 1) The pickup system is comprised of two separate transducer sensing units. These units are interchangeable as either may be used for either string course.
- 2) The light side of the pickup is the side that will come into contact with the dulcimer soundboard. The black side of the pickup will always face away from the sound board.
- 3) All sound boards will vary a bit in tonal response and output. For this reason it is suggested that each of the sensor units should be placed in the approximate center of their half of the sound board (with the sound board "divided" into equal left and right sides). These are suggested positions only, you may wish to try slightly different positions for the sensors if you need to change the treble to bass balance and related volumes.
- 4) The tape supplied will provide a very strong bond between the pickup and the soundboard. This tape should be considered as providing a permanent mounting and can prove to be very difficult to remove. If you are using this tape and have to remove the pickup, grasping the pickup firmly and rotating it slightly usually will help to free it up. Damage to the finish of the soundboard may result with the removal of this tape.
- 5) For stereo use, simply plug each sensor into a different amplifier or into different channels on a mixing board.
- 6) For mono use, plug each of the sensors into the 'Y' adapter before plugging into the amp or mixer.

Warranty

We warrant to the original purchaser that our pickups are free from defects in materials and workmanship for a period of 2 (two) years. Should a product fail to perform properly within the specified warranty period you may contact your dealer or Schatten Design for instructions. No product will be accepted for warranty return by Schatten Design without a Return Authorization number.

Modèle de système de collecte martelé Dulcimer HD2 par Schatten

Merci d'acheter un de nos systèmes de collecte martelés dulcimer. Chaque collecte est soigneusement faite à la main et examinée pour s'assurer qu'elle répond à nos normes élevées pour la qualité et la longévité.

Instructions d'installation :

- 1) Le système de collecte est composé de deux éléments capteurs séparés sensoriels. Ces éléments sont interchangeables car l'un ou l'autre peut être employé pour n'importe quel chemin de corde.
- 2) Le côté léger de la collecte est le côté qui entrera en contact avec le tableau sonore du dulcimer. Le côté noir de la collecte fera toujours face loin du tableau sonore.
- 3) Tous les tableaux sonores changeront un peu dans la réponse tonale et le rendement. Pour cette raison on le suggère que chacune des unités de sonde devrait être placée au centre approximatif de leur moitié du tableau sonore (avec le tableau sonore « divisé » en côtés égaux).
Ce sont des positions suggérées seulement, vous pouvez souhaiter essayer des positions légèrement différentes pour les sondes si vous avez besoin changer le triple en équilibre bas et volumes relatifs.
- 4) La bande fournie fournira un lien très fort entre la collecte et le tableau sonore. Cette bande devrait être considérée en tant que fournir un support permanent et il peut s'avérer très difficile à enlever. Si vous utilisez cette bande et devez enlever la collecte, tenez la collecte fermement et la rotation légère habituellement aidera à la libérer vers le haut. Dommages à la finition du tableau sonore peut résulter avec le déplacement de cette bande.
- 5) Pour l'usage stéréo, branchez simplement chaque sonde dans un amplificateur différent ou à différents canaux sur un tableau de mixage.
- 6) Pour l'usage mono, branchez chacune des sondes adaptateur « Y » avant de brancher à l'ampère ou au mixeur.

Garantie

Nous justifions à l'acheteur original que nos collectes sont exemptes des défauts en matériaux et de l'exécution pendant une période de 2 (deux) années. Si le produit échoue d'exécuter correctement au cours de la période indiquée de garantie vous pouvez entrer en contact avec votre revendeur ou concepteur de Schatten pour des instructions. Aucun produit ne sera admis pour le retour de garantie par Schatten Design sans numéro d'autorisation de retour.