

Schatten Jack Assembly SJA plus

Thank you for purchasing one of our jack assemblies. All have been designed to provide a solidly anchored output with little or no modification to the jack assembly or the instrument.

Please do not use a soldering iron larger than 35 watts as excessive heat may damage the volume control.

Installation Instructions: Steps #1 & #2 may not be necessary if SJA+ is purchased with pickup

- 1) From your pickup the outer shield wire is to be soldered to ground (-). The inner insulated wire is to be soldered to hot (+).
- 2) Lift the backing from the bottom of the SJAplus until the pot is exposed. Notice the two coloured dots. Red represents hot (+) and green represents ground (-). The outer shield of the pickup lead should be soldered to the green dot area while the centre insulated lead should be soldered to the red dot area.
- 3) Using a small allen key, attach the lower portion of the chin rest clamp to the 'legs' of the SJA+. Adjust positioning of the SJAplus onto the instrument accordingly. You can reposition the SJAplus as necessary.
- 4) Included with the SJAplus are a few extra strips of cork that you may stick to the underside of the unit if you find that the unit will not tighten to the instrument far enough.

Warranty

We warrant to the original purchaser that our jack assembly is free from defects in materials and workmanship for a period of 90 (ninety) days. Retain your sales invoice for the jack to provide date and proof of purchase. Contact your local retailer for details on returning items for warranty.

Assemblage SJA de Schatten Jack plus

Merci d'acheter un de nos crics. Tous ont été conçus pour fournir un résultat solidement ancré peu ou pas de modification au cric ou à l'instrument.

Veillez ne pas employer un fer à souder plus en grande partie que 35 watts comme la chaleur excessive peut endommager la commande de volume.

Instructions D'Installation: Les étapes #1 et #2 ne peuvent pas être nécessaires si SJA+ est acheté avec la collecte

- 1) De votre collecte le fil externe de bouclier doit être soudé à la terre (-). Le fil isolé intérieur doit être soudé à chaud (+).
- 2) Soulever le support du fond du SJA+ jusqu'à ce que le pot soit exposé. Notez les deux points colorés. Le rouge représente chaud (+) et vert représente la terre (-). Le bouclier externe du fil de collecte devrait être soudé au secteur vert de point tandis que le fil isolé par centre devrait être soudé au secteur rouge de point.
- 3) Employer une petite clef d'Allen, attachez la partie inférieure de la bride de repos de menton aux jambes de ` du SJA+ . Ajustez le positionnement du SJA+ sur l'instrument en conséquence. Vous pouvez replacer le SJA+ selon les besoins.
- 4) Incluses avec le SJA+ sont quelques bandes supplémentaires de liège que vous pouvez coller au dessous de l'unité si vous constatez que l'unité ne serrera pas à l'instrument assez loin.

Garantie

Nous justifions à l'acheteur original que notre cric est exempté des défauts en matériaux et de l'exécution pendant une période de 90 (quatre-vingt-dix) jours. Gardez vos factures pour que le cric fournisse la date et la preuve de l'achat. Contactez votre détaillant local pour des détails sur les articles de renvoi pour la garantie.